

RAM PROMASTER


REAR DOOR UPPER STORAGE PANELS




CAUTION

Please read all steps before you begin. Installation of this product requires drilling through the first layer of sheet metal on the inside of your van doors. Take caution not to drill farther than about 3/8" or you risk drilling through the outside of the door. VanEssential is not responsible for any mistakes made.

What's Included:



1X LEFT Rear Door Storage Panel




1X RIGHT Rear Door Storage Panel



Sheet Metal Screws


You Will Need:



Power Drill




3/32" Steel Drill Bit
with depth stop at 3/8"




T25 Screwdriver Bit


1. If applicable, remove all plastic stock trim so that your door has the metal frame exposed.




2. The panel is designed to be larger than the indentation located towards the top of the door. Hold up the panel and center it around the indent towards. You'll want to make sure it's out of the way of the rubber weather strip.




3. Starting in the upper left-hand corner, identify a spot between the two outer seams and carefully pre-drill a hole through the panel and into the van door.




4. Drive a screw into the hole, securing the panel in place.



5. Repeat this process in each corner, and add additional screws around the panel edge between the outer seams as needed for a secure fit.



6. Repeat steps 1-5 for the second panel on the opposite door. You will likely have leftover screws. Step back and admire your work!



RAM PROMASTER


REAR DOOR MIDDLE STORAGE PANELS



CAUTION

Please read all steps before you begin. Installation of this product requires drilling through the first layer of sheet metal on the inside of your van doors. Take caution not to drill farther than about 3/8" or you risk drilling through the outside of the door. VanEssential is not responsible for any mistakes made.

What's Included:




2X Rear Door Storage Panels



Sheet Metal Screws

You Will Need:



Power Drill



3/32" Steel Drill Bit
with depth stop at 3/8"




T25 Screwdriver Bit




A Friend


1. If applicable, remove all plastic stock trim so that your door has the metal frame exposed.




2. Have a friend help you hold up the panel to the window frame placing their hands on the left and right side of the cover. The panel edges **must** fold up against the edge of the window frame.




3. Starting on the top of the panel and in the center, identify a spot between the two outer seams and pre-drill a hole through the panel and into the van door on the window frame edge.




4. Drive a screw into the hole, securing the panel in place.



5. Repeat this process on the bottom of the panel in the center, **making sure to keep the panel perimeter folded against the window frame before drilling**. Then repeat this process on the left center and right side center. Add additional screws around the panel edges as needed for a secure fit.



6. Repeat steps 1-5 for the second panel on the opposite door. You will likely have leftover screws. Step back and admire your work!



RAM PROMASTER


REAR DOOR LOWER STORAGE PANELS



CAUTION

Please read all steps before you begin. Installation of this product requires drilling through the first layer of sheet metal on the inside of your van doors. Take caution not to drill farther than about 3/8" or you risk drilling through the outside of the door. VanEssential is not responsible for any mistakes made.

What's Included:




2X Rear Door Storage Panels




Sheet Metal Screws



T25 Screwdriver Bit



Power Drill



5/32" and 3/32" Steel Drill Bit with depth stop at 3/8"




A Friend


You Will Need:

NOTE: These panels are interchangeable and can be installed on either the left or right door.


1. If applicable, remove all plastic stock trim so that your door has the metal frame exposed.




2. Have a friend help you hold up and align the panel to the lower door frame, placing their hands on the left and right side of the cover.




3. Start by using your 5/32" steel drill bit. On the edge closest to the door hinge, identify a spot between the two outer seams and pre-drill a hole through the panel and into the van door. Drive a screw into the hole, securing the panel in place.



4. Repeat this process along the entire edge of the panel closest to the door hinge.



5. Switch to your 3/32" steel drill bit. Pre-drill holes between the two outer seams around the rest of the panel. Drive screws into the holes, securing the panel in place.



6. Repeat steps 1-5 for the second panel on the opposite door making sure to use the 5/32" drill bit on the edge closest to the door hinge. You will likely have leftover screws.

